

# GEN SERIES BINARY MARKER HV ISO

## Introduction

The Binary Marker HV board is a dedicated input option for GEN DAQ products. It enables to record up to 32 binary input channels (marker channels) as well as 8 digital event signals that are optically isolated with up to 1 MS/s per channel.

Although general purpose, this board is specifically suited for the high power/high voltage market. A fiber-optic isolated output is provided to present an ARM-signal that can be used to drive an external instrument like the HBM BE3200 high-definition test sequencer or any other timing device. The ARM output is active when a continuous recording is active, or when the acquisition card is waiting for a trigger (armed) in the triggered sweep acquisition mode.

In addition, 9 binary input channels can be assigned under software control to provide 3 channels of counter/timer functionality. Each channel can have its own function.

The counter/timer functionality includes:

- General purpose up/down counter
- Frequency/RPM counter
- Quadrature/ position measurements

The counter/timer functionality uses up to 3 event bits per channel. These event bits also keep their original functionality. E.g. you can use a quadrature encoder and at the same time look at the quadrature signals separately.

The HBM Perception software provides integrated display and control of the event channels, that are recorded in parallel with the analog channels.

A full range of features is available for each channel separately to make the best use of the event channels.

Settings include name, units, invert, and storage on/off.

In addition each event channel can be used as a trigger condition, a qualifier or an alarm. Each of these conditions can be set to either positive/negative or high/low active.

This combination of features gives you the capability to create complete "bit patterns" to be used as trigger or qualifier.

Note: The Counter/timer channels cannot be used for triggering nor alarm.

## General

**# of channels** 8 fiber-optic isolated marker (event) inputs;  
32 non isolated marker (event) inputs;  
1 fiber-optic isolated ARM output

**Counter/timer** 3 channels, providing:

- up/down counter
- Frequency/RPM count
- Quadrature measurement

**Sample rate** 1 MS/s

**Memory** 512 MByte total;  
The memory splits between marker inputs and counter/timers channels.

Usable memory is:

**Markers enabled only (1-40)**  
-> 64 MSamples

**Markers plus 1 counter chn enabled**  
-> 32 MSamples

**Markers plus 2 counter chn enabled**  
-> 20 MSamples

**Markers plus 3 counter Chn enabled**  
-> 16 MSamples

## Non-isolated inputs

**Input type** TTL, active low with pull-up resistor to enable activation by relais or short-circuit to ground

**Pull-up** 25.5 kΩ @ 5 Volt

**Output power** 0.3 A maximum

**Input range** TTL compatible, 30 V maximum

**Hysteresis** 1.3 V

**Threshold** - 28 V to + 0.7 V = '0'  
+ 2 V to + 28 V = '1'

**Protection** ± 30 V continuous

**Connectors** two 26-pin SubD type connectors with 16 events per connector

**Type** KF66-A26P-N

## Fiber-optic I/O

**Sockets** **Input:** HP HFBR-2523  
**Output:** HP HFBR-1523 (660 nm LED)

**Connectors** HP HFBR-4503 simplex latching connector

**Output drive** 60 to 100 meter

**Compatibility** fully compatible with HBM BE3200 Test Sequencer

## Fiber-optic cable (recommended)


**Type** plastic, single step index, HP HFBR-RXXYYY series core and cladding: 1.00 mm

**Diameter** 0.22 dB/m

**Attenuation** propagation delay constant: 5.0 ns/m




The Binary Marker HV board is a special solution developed for HighPower/High Voltage applications.




MARKERS



COUNTER



FREQ./RPM



QUADRATURE



Use fiber-optic cables for full isolation and measure with complete confidence.



## Binary Marker HV iso Specifications

### Conditional functionality (markers only)

<b>Modes Trigger</b>	trigger, qualifier, alarm <b>modes:</b> off, rising edge active, falling edge active <b>combination:</b> each event trigger is OR-ed with all other trigger sources
<b>Qualifier</b>	<b>modes:</b> off, active high/low <b>combination:</b> each event qualifier is AND-ed with all other qualifier sources
<b>Alarm</b>	<b>modes:</b> off, active high, active low

### Output functionality

<b>ARM (status)</b>	active when continuous recording active, or armed in triggered sweep mode
---------------------	---

### Counter/timer functionality

#### Timer/Counter

<b># of channels</b>	3
<b># of pins/channel</b>	3 (Eventbits 53 to 64)
<b>Function</b>	<ul style="list-style-type: none"> <li>• Clock</li> <li>• Direction</li> <li>• Reset</li> </ul>
<b>Sample size</b>	64 Bits (8 Bytes)
<b>Operation modes</b>	<ul style="list-style-type: none"> <li>• Counter</li> <li>• Quadrature counter</li> <li>• RPM</li> <li>• Frequency</li> </ul>

### Counter mode

<b>Count size</b>	64 bits
<b>Max frequency</b>	10 MHz
<b>Direction</b>	Up/Down by external pin
<b>Reset to "o"</b>	<ul style="list-style-type: none"> <li>• Manual by user</li> <li>• At start of Recording</li> <li>• By reset pin once after start of recording</li> <li>• By reset pin always</li> </ul>

### Quadrature Counter mode

<b>Count size</b>	64 bits
<b>Max frequency</b>	10 MHz
<b>Quadrature</b>	Up/Down by phase of signals
<b>Reset to "o"</b>	<ul style="list-style-type: none"> <li>• Manual by user</li> <li>• At start of Recording</li> <li>• By reset pin once after start of recording</li> <li>• By reset pin always</li> </ul>

### RPM measurement

<b>Sample size</b>	64 bits
<b>Max frequency</b>	10 MHz
<b>Direction</b>	Positive/Negative rotation
<b>Gate time</b>	User selectable 1 us to 10 sec in 1, 2, 5 steps
<b>Inaccuracy</b>	10 nsec/gate time
<b>Measurement</b>	Counts and period
<b>Pulse per rotation RPM</b>	User selectable Counts/(period * pulse per rotation)

### Frequency measurement

<b>Sample size</b>	64 bits
<b>Max frequency</b>	10 MHz
<b>Direction</b>	Positive/Negative rotation
<b>Gate time</b>	User selectable 1 us to 10 sec in 1, 2, 5 steps
<b>Inaccuracy</b>	10 nsec/gate time
<b>Measurement</b>	Counts and period
<b>Frequency</b>	Counts/period



Combine the board directly with other fibre-optic controlled equipment like the HBM BE3200 Test Sequencer.

Head Office  
HBM  
Im Tiefen See 45  
64293 Darmstadt, Germany

Tel: +49 6151 8030  
Email: info@hbm.com

France  
HBM France SAS  
46 rue du Champoreux, BP76  
91542 Mennecey Cedex

Tel: +33 (0)1 69 90 63 70  
Email: info@fr.hbm.com

Germany  
HBM Sales Office  
Carl-Zeiss-Ring 11-13  
85737 Ismaning

Tel: +49 89 92 33 33 0  
Email: info@hbm.com

UK  
HBM United Kingdom  
1 Churchill Court, 58 Station Road  
North Harrow, Middlesex, HA2 7SA

Tel: +44 (0) 208 515 6100  
Email: info@uk.hbm.com

USA  
HBM, Inc.  
19 Bartlett Street  
Marlborough, MA 01752, USA

Tel : +1 (800) 578 4260  
Email: info@usa.hbm.com

PR China  
HBM Sales Office  
Room 2912, Jing Guang Centre  
Beijing, China 100020

Tel: +86 10 6597 4006  
Email: hbmchina@hbm.com.cn

