# **GENESIS HIGHSPEED**



# **Specifications**

# **GEN SERIES BRIDGE 1M ISO DIGITIZER** WITH FULL DIFFERENTIAL MODE

#### Bridge 1M iso Digitizer

| Bridge 1M iso Digitizer |                                     |  |  |  |
|-------------------------|-------------------------------------|--|--|--|
| Analog Input S          | ection                              |  |  |  |
| Number of               | 4                                   |  |  |  |
| Channels                |                                     |  |  |  |
| Input Type              | Fully isolated bridge or            |  |  |  |
|                         | fully isolated full                 |  |  |  |
|                         | differential, software              |  |  |  |
|                         | selectable                          |  |  |  |
| Input                   | Lemo 16-pin,                        |  |  |  |
| Connectors              | mating connector:                   |  |  |  |
|                         | FGG2B316CLA52                       |  |  |  |
| Input Ranges            | ± 2 mV, ± 5 mV, ± 10 mV,            |  |  |  |
|                         | ± 20 mV, ± 50 mV, ± 100 mV,         |  |  |  |
|                         | ± 200 mV, ± 500 mV, ± 1 V,          |  |  |  |
|                         | ± 2 V, ± 5 V, ± 10 V                |  |  |  |
| Gain                    | 5000, 2000, 1000, 500,              |  |  |  |
| (± 10 V ÷ range)        |                                     |  |  |  |
| Offset                  | 1000 steps (0.1 %)                  |  |  |  |
| (zero position)         |                                     |  |  |  |
| Input Coupling          |                                     |  |  |  |
|                         | DC, GND                             |  |  |  |
| Input                   | 2x 10 MΩ // 130 pF                  |  |  |  |
| Impedance               |                                     |  |  |  |
| Analog                  | > 120 kHz at maximum                |  |  |  |
| Bandwidth               | gain (ranges ≤ ± 20 mV),            |  |  |  |
|                         | 450 kHz at minimum gain             |  |  |  |
| CMRR                    | > 72 dB @ 100 Hz                    |  |  |  |
| CMV                     | ± 10 V to amplifier ground          |  |  |  |
| Over the set            | ± 50 V to isolated ground           |  |  |  |
| Overload                | 35 Volt                             |  |  |  |
| Protection<br>Number of | , including signal                  |  |  |  |
|                         | 1, including signal<br>conditioners |  |  |  |
| Slots                   | conditioners                        |  |  |  |
|                         |                                     |  |  |  |
|                         |                                     |  |  |  |

| Bridge Support     |   |
|--------------------|---|
| Completion         | Half bridge: 2x 10 kΩ<br>Quarter bridge*: 350Ω,<br>and user-defined,<br>software selectable,<br>auto balance  |
| Excitation Voltage | Off, ± 1.0 V to ± 7.5 V in<br>1000 steps, up to 85<br>mA per channel  |
| Balance Voltage    | +/- 250mV max<br>unbalance voltage<br>compensation  |
| Remote Sensing     | 2 separate sense wires<br>or internal   |
| Excitation Current | Off, 2 mA to 40 mA,<br>15 V compliance  |
| Shunt Calibration  | 2 pre-installed<br>calibration resistors*<br>(20 k $\Omega$ , 100 k $\Omega$ ), one<br>user-defined, plus<br>external, shunt to + or<br>– excitation<br>Two to ten wire incl. |
| Configurations     | driven guard  |
| Isolation          |   |

#### Isolation

Channel-to-chassis 50 Volt peak Channel-to-channel 100 Volt peak Non-destructive 100 Volt to chassis (earth) **Error and Noise** Maximum 0.1 % of FS ± 40 µV Static Error Noise (RMS) 0.02 % of FS ±30µV

#### Acquisition

| Sample Rate<br>ADC Resolution<br>Timebase Accuracy<br>Anti-Alias Filters | From 1 MS/s to 0.1 S/s<br>16 bit (0.0015 %)<br>50 ppm<br>Bypass, Time-,<br>Frequency domain<br>optimized                      |
|--|---|
| Time Domain  | 7-pole Bessel 250 kHz, optimal step response  |
| Frequency<br>Domain<br>Digital   | 7-pole Butterworth<br>400 kHz, extended<br>frequency response<br>Off, IIR or FIR  |
| Decimation Filters   |   |
| Time Domain<br>Frequency Domain  | 6-pole Bessel style IIR,<br>sample rate divided by<br>10, 20, 40, 100<br>12-pole FIR, sample rate<br>divided by 4, 10, 20, 40 |
|  |   |

# **Transient Memory**

256 MS per card, shared by enabled channels. 4 channels 64 MS per channel

## Triggering

Each channel has a dual-level trigger detector with selectable hysteresis, modes and qualifiers. Pre- and o to full memory length post-trigger **Trigger Rate** Up to 200 triggers per second, zero re-arm time 16 bit for each level Resolution (= 0.0015 %)

### StatStream Real-time Analysis

Each channel includes real-time extraction of Max, Min, Mean, Peak-to-peak, and RMS values.

## **Acquisition Modes**

| Sweeps<br>Continuous | Triggered acquisition to<br>RAM without sample rate<br>limitations; for single or<br>repetitive transients or<br>intermittent phenomena<br>Direct storage to PC or<br>mainframe hard disc<br>without file size limitations;<br>triggered or untriggered; for   |  |  |
|----------------------|--|--|--|
| Dual                 | long duration recorder type<br>applications with up to 1<br>MS/s rate per channel;<br>(maximum aggregate rate<br>pending from mainframe<br>configuration and PC)<br>Combination of Sweeps and<br>Continuous; recorder type<br>streaming to hard disc with<br>simultaneously triggered<br>sweeps in RAM |  |  |



\* These are metal-foil high-performance instrumentation resistors with a tolerance of 0.1% and a TCR of 0.6 ppm/°C

| <b>Head Office</b><br>HBM<br>Im Tiefen See 45<br>64293 Darmstadt, Germany | <b>France</b><br>HBM France SAS<br>46 rue du Champoreux, BP76<br>91542 Mennecy Cedex | <b>Germany</b><br>HBM Sales Office<br>Carl-Zeiss-Ring 11-13<br>85737 Ismaning | <b>UK</b><br>HBM United Kingdom<br>1 Churchill Court, 58 Station Road<br>North Harrow, Middlesex, HA2 7SA | <b>USA</b><br>HBM, Inc.<br>19 Bartlett Street<br>Marlborough, MA 01752, USA | <b>PR China</b><br>HBM Sales Office<br>Room 2912, Jing Guang Centre<br>Beijing, China 100020 | E |
|---|--|---|---|---|--|---|
| Tel: +49 6151 8030<br>Email: info@hbm.com                                 | Tel: +33 (0)1 69 90 63 70<br>Email: info@fr.hbm.com                                  | Tel: +49 89 92 33 33 0<br>Email: info@hbm.com                                 | Tel: +44 (o) 208 515 6100<br>Email: info@uk.hbm.com   | Tel : +1 (800) 578 4260<br>Email: info@usa.hbm.com                          | Tel: +86 10 6597 4006<br>Email: hbmchina@hbm.com.cn  | H |

www.hbm.com/highspeed

HBM Genesis HighSpeed products were previously sold under the Nicolet brand. The Nicolet brand is owned by Thermo Fisher Scientific Inc. Corporation.

HBM reserves the right to change this document without notice. It provides outline specification only and cannot be used as the basis of any contract.